



- ①註：
- 1.計器變流器 IC-35 (電流表用) .
 - 2.電流表
 - 3.指示燈
 4. PP-2 按鈕開關
- 上述4種器具在 YNB-220 機種才安裝

①
YN(B)-220
(+RHN-10+RP-10)