


Connecting plate 1600A



Operation handle outside the cabine  
Panel installation size diagram